



THE EASTERN SPECIALTY COMPANY

OPERATIONS

MANUAL

THREE PHASE METER TEST BOARD

PRODUCT:

MTS-3050

THREE PHASE METER TEST BOARD OPERATIONS MANUAL MTS-3050



THE EASTERN SPECIALTY COMPANY

© 2019 TESCO - The Eastern Specialty Company

All Rights Reserved.

Specifications are subject to change without prior notice.

Revision: 1.0

TESCO – The Eastern Specialty Company

925 Canal Street Bristol, PA, 19007

Phone: 215.785.2338

info@tescometering.com

www.tescometering.com

LIMITED WARRANTY & LIMITATION OF LIABILITY

TESCO warrants to the original purchaser that it will correct all defects in material and/or workmanship in the Instrument, test equipment or software covered by this warranty (herein called "**PRODUCT**"), provided that TESCO is notified of such defect within the warranty period (set forth below) in accordance with paragraph four of this Warranty.

WARRANTY PERIOD. The warranty period shall begin on the date of shipment of the **PRODUCT** or the date of the issuance of this warranty certificate, whichever is later. If no warranty period is specified below and signed by an authorized **DISTRIBUTOR** of TESCO, the Warranty Period shall be one (1) year. In no event shall this Warranty remain in effect for more than the stated Warranty Period plus two (2) months after the date of shipment. TESCO's sole obligation and the purchaser's sole remedy under this Warranty is limited to repair or replacement, at TESCO's option, free of charge, F.O.B. TESCO's factory at Bristol, PA of any workmanship and/or part which in TESCO's sole judgment displays evidence of defect. On-site Warranty repairs will be made when in TESCO's judgment the **PRODUCT** cannot practically be shipped to TESCO's factory. Any modifications, additions or upgrades made to the **PRODUCT** or control software after this warranty becomes effective shall not extend the term of this warranty.

COVERAGE. The warranty set forth above shall be applicable only if the **PRODUCT**:

1. Is used for the specific purpose for which it was intended;
2. Is operated in accordance with instructions, if any, supplied by TESCO;
3. Has not been modified, neglected, altered, tampered with, vandalized, abused or misused, or subjected to accident, fire, flood or other casualties;
4. Has not been repaired by unauthorized persons;
5. Has not had its serial number altered, defaced or removed;
6. Has not been connected, installed or adjusted other than in accordance with the instructions, if any, furnished by TESCO.

The warranty set forth herein DOES NOT APPLY to defects resulting from ordinary wear, tear and usage, or any cause, similar or dissimilar, not resulting solely from defective material and/or workmanship.

The Warranty set forth herein shall NOT be effective unless:

1. Notice of defect is given to TESCO by phone, fax, email or mail as soon as the defect is discovered.
2. Notice of defect contains the following information: PRODUCT serial number, PRODUCT model number, date of original installation, and an accurate and complete description of the defect including the exact circumstances leading to the defect.
3. The defective PRODUCT or part is returned only upon authorization from TESCO as evidenced by the issuing of a Return Merchandise Authorization (RMA) number, and that the transportation charges are prepaid (except that TESCO may, at its option, appoint a qualified DISTRIBUTOR to make field inspections of the PRODUCT for which purpose the purchaser shall permit such DISTRIBUTOR to enter upon its premises and examine the PRODUCT).
4. The Return Merchandise Authorization (RMA) number is written on the shipping label and all paperwork defective PRODUCT or part.
5. The defective PRODUCT or part is returned in the original packing or packing approved by TESCO

TESCO is not responsible for drayage charges, damages or labor costs incurred in conjunction with failure, removal or reinstallation of any PRODUCT, all of which shall be at the purchaser's expense. TESCO is not responsible for special, incidental or consequential damages, whether resulting from breach of warranty, negligence or any other reason.

TESCO manufactured parts will be available for a minimum period of at least two years after the manufacture of a PRODUCT has been discontinued.

TESCO will provide original purchaser during the Warranty Period, unlimited telephone consulting time for the purpose of PRODUCT trouble shooting/servicing and for the first thirty (30) days of the Warranty Period, unlimited telephone consulting time for the purpose of PRODUCT/software application.

THE WARRANTY CONTAINED HEREIN IS IN LIEU OF ALL OTHER WARRANTIES AND TESCO MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OR CONDITION, DESIGN, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR ANY OTHER MATTER.

No other Warranty, express or implied, is authorized by TESCO, and no DISTRIBUTOR of TESCO or any other person has any authority to amend, extend, modify, enlarge or otherwise alter the foregoing warranty and disclaimers in any way whatsoever, except as provided for in an Extended Limited PRODUCT Warranty Agreement.

TABLE OF CONTENTS

1.0 INTRODUCTION	1
1.1 Introduction	2
1.2 Contacting TESCO.....	2
1.3 General Safety Summary.....	3
1.4 Description of Safety-related Icons.....	3
1.5 Protective Earth / Grounding	3
1.6 Product Features	4
1.6.1 Key Features	4
1.6.2 Standard Features.....	4
1.6.3 Optional Features	5
1.7 General Specifications.....	5
1.7.1 Input Characteristics	5
1.7.2 Dimensions	5
1.7.3 Measurements Accuracy	5
1.8 About this Operations Manual	6
2.0 INSTALLATION	7
2.1 Introduction	8
2.2 Unpacking and Inspection	8
2.3 Set up, Airflow and Cooling Considerations	8
2.3.1 Setup and Placement	8
2.3.2 Airflow.....	9
2.4 Main Power Supply	9
2.5 Utility Meter Insertion/Extraction	10
3.0 MTS-3050 FUNCTIONALITIES	11
3.1 Introduction	12
3.2 Front Panel Features	12
3.2.1 Front Panel Sections	12
3.3 The Graphical User Interface (GUI)	13
3.3.1 Graphical User Interface (GUI) Screens	13
3.3.2 MAIN MENU.....	14
3.3.3 MANUAL TEST.....	14

3.3.4	SINGLE TEST SETUP	16
3.3.5	TEST SELECTION	17
3.3.6	SEQUENCE TESTING	17
3.3.7	PLC TEST	19
3.3.8	DISCONNECT TEST	19
3.3.9	TIME & USER INFORMATION	20
3.3.10	SYSTEM INFORMATION	21
3.3.11	NETWORK SETUP	22
3.4	Optical Pickup Alignment	22
4.0	REMOTE OPERATIONS	23
4.1	Introduction	24
4.2	Installation	24
4.3	Network Configuration	24
4.4	Functionalities	24
4.4.1	NETWORK VIEW	24
4.4.2	METER TEST	25
4.4.3	METER DATABASE	25
4.4.5	TEST SEQUENCE	25
4.4.6	MANUAL SETUP	26
5.0	MAINTENANCE	27
5.1	Introduction	28
5.2	Replacing the Fuse	28
5.3	Cleaning the Air Filters	29
5.4	Cleaning the Instrument External Surface.....	30
6.0	CONFIGURATIONS.....	31
6.1	Single Test	32
6.2	Sequence Test.....	32
6.3	Disconnect Test.....	33
6.4	PLC Test.....	34
7.0	FREQUENTLY ASKED QUESTIONS.....	35
7.1	Introduction	36
7.2	Test	36
7.3	Software.....	36

7.4 Hardware..... 36

8.0 TROUBLESHOOTING..... 37

8.1 Troubleshooting 38

1.0 INTRODUCTION

1.1 Introduction	2
1.2 Contacting TESCO.....	2
1.3 General Safety Summary.....	3
1.4 Description of Safety-related Icons.....	3
1.5 Protective Earth / Grounding	3
1.6 Product Features	4
1.6.1 Key Features	4
1.6.2 Standard Features.....	4
1.6.3 Optional Features	5
1.7 General Specifications.....	5
1.7.1 Input Characteristics	5
1.7.2 Dimensions	5
1.7.3 Measurements Accuracy	5
1.8 About this Operations Manual	6

1.1 Introduction

An innovative meter ACCURACY test system offering unsurpassed functionality and ease of use!

Need to run standard meter accuracy tests? Looking for an instrument that can perform complex meter accuracy tests under widely varying load conditions? If so, all you need is TESCO's revolutionary Three Phase Meter Test Board (MTS-3050)!

The 3050 offers features that you will need to test meters today and tomorrow in a compact, desktop package.

It is fully functional in testing all AMI/AMR meters. It can perform Manual Test, Sequence Testing, PLC Test, and Disconnect Test for meters with a wide array of forms. It has a database for storing and viewing of the test data. It has all the waveforms called out in ANSI C12.20-2015 (pub. 4/2017) with the new waveform generator.

For more than 110 years customers have trusted TESCO for accuracy and reliability. When you think metering, think TESCO.

MTS-3050 will be referred as "Instrument" all throughout the operational manual.

1.2 Contacting TESCO

To contact TESCO, call one of the following telephone numbers:

- Technical Support: 215.785.2338
- Calibration/Repair: 215.785.2338
-

Visit our website at www.tescometering.com or send an email to info@tescometering.com.

To view, print, or download the latest manual supplement, visit www.tescometering.com.

1.3 General Safety Summary

This manual contains information and warnings that must be observed to ensure safe operation and keep the Instrument in a safe condition. Operation or service in conditions or in a manner other than specified could compromise safety. For the correct and safe use of this device, it is essential that both operating and service personnel follow accepted safety procedures in addition to the safety precautions specified.

In this manual, a **WARNING** identifies conditions and actions that pose hazard(s) to the user, while a **CAUTION** identifies conditions and actions that may damage the Instrument or the test equipment.

WARNING

To avoid electrical shock, personal injury, or fire hazard:

- The device must not be switched ON if it is damaged or suspected to be faulty.
- Do not operate the device in wet, condensing, dusty, or explosive gas conditions.
- If the equipment is used in a manner not specified in this manual, the protection provided by the Instrument may be impaired.
- Whenever it is likely that safety protection has been impaired, the device must be made inoperative and be secured against any unintended operation. Inform qualified maintenance or repair personnel.
- Safety protection is likely to be impaired if, for example, the Instrument displays visible damage or fails to operate normally.

1.4 Description of Safety-related Icons

ICONS	DESCRIPTION
	Risk of danger. Important information. See manual.
	Hazardous voltage. Risk of electrical shock.

1.5 Protective Earth / Grounding

WARNING

To avoid electrical shock or personal injury, do not intentionally or unintentionally interrupt the protective ground conductor inside or outside the Instrument. Interrupting the protective ground conductor is likely to make the Instrument dangerous. Intentional interruption is prohibited

1.6 Product Features

1.6.1 Key Features

- **Precise Measurement Accuracy for Voltage, Current & Power**
 - Simultaneous time and frequency domain measurements
- **Accurate Voltage and Current Setting**
- **Digital Waveform Generator**
 - Voltage Drive: 350V RMS (phase to neutral), 600V-848V PK (phase-to-phase)
 - Current Drive: 0.01A to 50A RMS, 70A PK
 - Arbitrary harmonically defined waveforms
 - Automatic Generation of all ANSI C12.20-2015 waveforms
- **True ZERO insertion force socket with automatic closure on meter insertion**
- **Powerful, multi-core, 32-bit processors**
- **Phase Fully adjustable as phase or power factor**
- **Built in, one voltage, three current reference standards traceable back to NIST**
- **Disconnect testing with supplemental power transformer**
- **Demand, time-run, and timed registration test capabilities**

1.6.2 Standard Features

- **GRAPHICAL USER INTERFACE (GUI)**
Displayed on a 7" 800x480, full color TFT LCD screen
- **ETHERNET CONNECTIVITY**
100 BaseT with support for: Web Services, Remote Control, Database Access. 7" RJ45 standard (blue) and crossover (red) cables are provided.
- **INTEGRATED CONTROL KEYPAD**
The keypad is embedded in the front panel.
- **METER FORMS SUPPORT** (*Please inquire for adding any other meter forms*)
1S-6S, 8S-17S, 25S, 26S, 29S, 32S, 35S, 36S, 45S, 46S, 56S, 66S, 76S, 103S, 106S, 109S, 112S, 116S, 125S, 135S, 136S, 145S, 166S
- **TEST MANAGER APPLICATION (TMA) INTEGRATION**
Computer control software package to enable full control of the board and test data storage via external PC.
- **OPTICAL PICKUP**
The Instrument comes with an optical pickup

1.6.3 Optional Features

- A-Base Test Board Adapter
- 1180 K-Base Test Board Adapter
- Adapter for calibrating the unit
- Diamond Support with Calibration Service
- Stand-alone calibration of the unit
- Wedge (2490) and Mechanical Pickup (2480) for testing mechanical meters

1.7 General Specifications

1.7.1 Input Characteristics

PARAMETERS	DATA
Power Supply	120 VAC, 10A
Supply Frequency	45-65Hz

1.7.2 Dimensions

PARAMETERS	DATA
Height	18.6" (47.24 cm)
Width	25.54" (64.87 cm)
Depth	25.62" (65.07 cm)
Weight	144 lbs (65.31 kg)

1.7.3 Measurements Accuracy

Valid for 50Hz/60Hz and Current of 0.2A to 50A. Optional reference standard of 0.02% and 0.01%.

PARAMETERS	DATA
Voltage Measurement Accuracy	±0.02%
Current Measurement Accuracy	±0.02%
Power Measurements Accuracy (Watts / VA / VAR)	±0.04%
Energy Measurements Accuracy (WHrs / VAHrs / VARHrs)	±0.04%

1.8 About this Operations Manual

This manual provides complete information for installing and operating the Instrument. This document instructs the user on the following operations of the MTS-3050:

- Installation
- Front Panel Features
- Graphical User Interface (GUI)
- How to set up the machine for remote operation using PC Application
- Instrument Maintenance

2.0 INSTALLATION

2.1 Introduction 8

2.2 Unpacking and Inspection 8

2.3 Set up, Airflow and Cooling Considerations 8

 2.3.1 Setup and Placement 8

 2.3.2 Airflow 9

2.4 Main Power Supply 9

2.5 Utility Meter Insertion/Extraction 10

2.1 Introduction

This chapter provides instructions for unpacking and installing the Instrument. Read this chapter before you operate the Instrument. Instructions for cable connections can be found here.

2.2 Unpacking and Inspection

The Instrument is shipped in a container designed to prevent damage during shipping.

Inspect the Instrument carefully for damage, and immediately report any damage to the shipper. A packing list is included in the packaging. When you unpack the Instrument, check for all the standard equipment listed and check the shipping order for any additional items ordered. Report any shortage to the place of purchase to your distributor or directly to TESCO.

2.3 Set up, Airflow and Cooling Considerations

2.3.1 Setup and Placement

The Instrument is suitable for bench top use if there is enough space to allow proper ventilation. Please see suggested placement of the setup.




Figure 2.3a Benchtop Suggested Setup


IMPORTANT CONSIDERATIONS:

Since the Instrument is a benchtop device, the table should:

- 1- Be stable (should not have loosely, shaky joints)
- 2- Have table legs that are stationary or non-rollers. In case rollers are present, ensure that the rollers are properly locked to avoid unnecessary movements.

2.3.2 Airflow

Take note of the Instrument's airflow as seen in the illustration. This always for a table top, never on a rack. Please allow enough airspace at the side with at least half a meter for an effective airflow.



CAUTION


Damage caused by overheating may occur if the area around the air intake is restricted, the intake air is too warm, is interfered, or the air filter becomes clogged.

The inlet and exhaust holes must be clear of obstruction. The air entering the instrument must be between 5 °C and 35 °C. Make sure that exhaust from another instrument is not directed into the fan inlet.

Check and clean the air filter every 30 days or more frequently if the Instrument is operated in a dusty environment. Refer to §5.3 for additional info.

2.4 Main Power Supply

The Instrument can be powered by plugging it to a 120V-Single Phase AC line. An AC line power cord is provided.



- 1- Power Switch
- 2- 5A Fuse
- 3- 3-prong Single Phase 120V AC Line

WARNING 

The Instrument should only be plugged to an AC outlet with a 90 – 120V voltage range to avoid damaging the Instrument.


To avoid electrical shock, personal injury, or fire hazard, connect the factory-supplied three-conductor-line power cord to a properly grounded power outlet.

During test operation, a two-conductor adapter or extension cord **MUST NOT** be used. This will break the protective ground connection and will affect the measurement accuracy of the Instruments.

The power outlets supplying the Instrument system should be controlled by an emergency switch so that power can be switched off if a hazard arises.

2.5 Utility Meter Insertion/Extraction

The electric meter socket requires **zero insertion force** to mount a meter, as well as to dismount it, upon pressing the meter release button.



WARNING  

When mounting a meter, the Instrument must be switched OFF. In both mounting or dismounting a meter, the Instrument should not be performing a test to avoid electrical shock, personal injury, or fire hazard.

The meter release button* is only operational when the Instrument is powered up. No meter can be dismantled when the Instrument is powered off.

*When the button lights up in glowing red, it can be pressed to dismount a meter.

INSERTION: To load a meter into the socket, ensure meter is oriented properly. Then insert meter into socket, keeping the meter weight fully supported. The device will automatically clamp to the jaws of the meter. When the METER RELEASE indicator turns on, the meter is fully supported. Align optical pickup to meter prior to testing.

EXTRACTION: To remove the meter from the socket, ensure optical pickup is removed from the face of the meter. Support the meter shell then press the METER RELEASE button. Once the METER RELEASE indicator turns off, the meter is safe for removal from the socket.

NOTE: The socket cannot be powered unless a meter is installed, and if the release button is pressed, power to the socket will be shut off.

3.0 MTS-3050

FUNCTIONALITIES

3.1 Introduction	12
3.2 Front Panel Features	12
3.2.1 Front Panel Sections	12
3.3 The Graphical User Interface (GUI)	13
3.3.1 Graphical User Interface (GUI) Screens	13
3.3.2 MAIN MENU.....	14
3.3.3 MANUAL TEST.....	14
3.3.4 SINGLE TEST SETUP	16
3.3.5 TEST SELECTION	17
3.3.6 SEQUENCE TESTING	17
3.3.7 PLC TEST.....	19
3.3.8 DISCONNECT TEST	19
3.3.9 TIME & USER INFORMATION	20
3.3.10 SYSTEM INFORMATION	21
3.3.11 NETWORK SETUP	22
3.4 Optical Pickup Alignment	22

3.1 Introduction

This chapter is a reference for the functions and locations of the Instrument's front panel features and provides brief descriptions of each feature for quick access. **Please read this information before operating the Instrument.** Front panel operating instructions for the Instrument are provided in this chapter and Remote Operating instructions are in Chapter 4.

3.2 Front Panel Features

Front panel features (including all controls, displays, indicators, and terminals) are shown in Figure 3.2.1a. Each front panel feature is briefly described in Table 3.2.1.

3.2.1 Front Panel Sections




Figure 3.2.1a MTS-3050 Front Panel

NUMBER	DESCRIPTION
1	LAN port
2	Power switch
3	Probe arm
4	Meter socket
5	Meter release button
6	LCD screen
7	Fast access buttons
8	Function buttons
9	Power button
10	Navigation buttons
11	Duplex Utility Receptacle
12	Keypad
13	Optical Pickup port
14	Disconnection Test indicators

Table 3.2.1. MTS-3050 Front Panel Sections


3.2.2 Navigation Keys

Symbol	Description
	Functions any of the following: <ul style="list-style-type: none"> Selects the NEXT or PREVIOUS MENU item. Moves the SELECTED LINE UP or DOWN Select an Item from a dropdown menu
	Functions any of the following: <ul style="list-style-type: none"> Moves the cursor left/right of the current character in text boxes. Moves the selection left/right of the current selected cell in tables.
	Selects the NEXT or PREVIOUS TAB item.
	Press to highlight the form entry list box. A form can be selected from the list by using the UP or DOWN ARROWS or directly entered using the numeric keypad.
	Press to highlight the voltage entry text box. Any voltage between 30.00 to 480.00 volts can be entered.
	Press to highlight the current entry text box. Any current between 0.1 and 50.00 amps can be entered. If the selected form is a transformer rated form then the maximum will be restricted to 20.00 amps.
	Press to highlight the phase entry box. Any phase between -359.9 to 359.9 degrees can be entered. When reverse is selected, it has the effect of adding 180 degrees to the current vector.
	Deletes the previous character
	Returns to the previous screen
	Function Keys
	Power button
	Selects a response

3.3 The Graphical User Interface (GUI)

3.3.1 Graphical User Interface (GUI) Screens


The user interface is divided into four sections. In the screen, any field that is grayed out cannot be changed or accessed by the user.




NUMBER	DESCRIPTION
1	Screen Title
2	Drive Indicator
3	Screen Data
4	Function Buttons




Table 3.3.1. MTS-3050 GUI Sections

MAIN MENU

SCREEN	DESCRIPTION									
	<p>3.3.2.1 MAIN MENU</p> <p>The MAIN MENU screen consists of the following function buttons: MANUAL, TESTS, & SETUP. Press arrow keys to navigate through the main menu or directly press the function keys.</p> <p>KEYPAD & FUNCTION KEYS:</p> <table border="1" data-bbox="837 470 1430 611"> <tr> <td>F1</td> <td>MANUAL</td> <td>Press to open the DRIVE SETUP screen</td> </tr> <tr> <td>F2</td> <td>TESTS</td> <td>Press to open the TEST SELECTION screen</td> </tr> <tr> <td>F4</td> <td>SETUP</td> <td>Press to open the SETUP MENU screen</td> </tr> </table> <p>To return to the previous screen press  at any time.</p>	F1	MANUAL	Press to open the DRIVE SETUP screen	F2	TESTS	Press to open the TEST SELECTION screen	F4	SETUP	Press to open the SETUP MENU screen
F1	MANUAL	Press to open the DRIVE SETUP screen								
F2	TESTS	Press to open the TEST SELECTION screen								
F4	SETUP	Press to open the SETUP MENU screen								

3.3.2 MANUAL TEST


SCREEN	DESCRIPTION																														
	<p>3.3.3.1 DRIVE SETUP</p> <p>DRIVE SETUP is for manual setup the waveform generator. Once manual setup is configured to desired test, run a single test by pressing the UNIT TEST button.</p> <p>KEYPAD & FUNCTION KEYS</p> <table border="1" data-bbox="837 1136 1430 1409"> <tr> <td>F1</td> <td>VOLTAGE ON</td> <td>Press to enable service voltage only to the socket</td> </tr> <tr> <td>F2</td> <td>LOAD ON</td> <td>Press to enable service voltage & load current to the socket</td> </tr> <tr> <td>F3</td> <td>STATS</td> <td>Press to display live voltage and current data on DRIVE ACTIVE screen.</td> </tr> <tr> <td>F4</td> <td>UNIT TEST</td> <td>Press to open to the METER INFO screen.</td> </tr> </table> <p>DATA</p> <table border="1" data-bbox="837 1461 1403 1759"> <tr> <td>FORM</td> <td>Form number of the meter (auto-populates the default Kh in the Kh field)</td> </tr> <tr> <td>SERVICE</td> <td>Services available for selected meter form</td> </tr> <tr> <td>WAVEFORM</td> <td>Waveform setup for the test</td> </tr> <tr> <td>VOLTAGE</td> <td>Voltage generated by Instrument</td> </tr> <tr> <td>FREQ.</td> <td>Frequency (Hz) of generated waveform</td> </tr> <tr> <td>CURRENT</td> <td>Current generated by Instrument</td> </tr> <tr> <td>ENABLE</td> <td>Toggle to enable or disable a certain phase</td> </tr> <tr> <td>PHASE</td> <td>Current phase angle with respect to A phase voltage</td> </tr> <tr> <td>PF</td> <td>Power Factor</td> </tr> </table> <p>WARNING: If either VOLTAGE ON or LOAD ON is enabled, the  indicator will change to . This indicates there is potential and/or current present at the meter terminals.</p>	F1	VOLTAGE ON	Press to enable service voltage only to the socket	F2	LOAD ON	Press to enable service voltage & load current to the socket	F3	STATS	Press to display live voltage and current data on DRIVE ACTIVE screen.	F4	UNIT TEST	Press to open to the METER INFO screen.	FORM	Form number of the meter (auto-populates the default Kh in the Kh field)	SERVICE	Services available for selected meter form	WAVEFORM	Waveform setup for the test	VOLTAGE	Voltage generated by Instrument	FREQ.	Frequency (Hz) of generated waveform	CURRENT	Current generated by Instrument	ENABLE	Toggle to enable or disable a certain phase	PHASE	Current phase angle with respect to A phase voltage	PF	Power Factor
F1	VOLTAGE ON	Press to enable service voltage only to the socket																													
F2	LOAD ON	Press to enable service voltage & load current to the socket																													
F3	STATS	Press to display live voltage and current data on DRIVE ACTIVE screen.																													
F4	UNIT TEST	Press to open to the METER INFO screen.																													
FORM	Form number of the meter (auto-populates the default Kh in the Kh field)																														
SERVICE	Services available for selected meter form																														
WAVEFORM	Waveform setup for the test																														
VOLTAGE	Voltage generated by Instrument																														
FREQ.	Frequency (Hz) of generated waveform																														
CURRENT	Current generated by Instrument																														
ENABLE	Toggle to enable or disable a certain phase																														
PHASE	Current phase angle with respect to A phase voltage																														
PF	Power Factor																														

SCREEN	DESCRIPTION																																						
<p style="text-align: center;">DRIVE SETUP</p>  <p style="text-align: center;">TEMPERATURES</p> 	<p>3.3.3.2 DRIVE ACTIVE</p> <p>This screen displays the operational statistics of the test being conducted.</p> <p>FUNCTION KEYS</p> <table border="1" data-bbox="844 336 1404 388"> <tr> <td>TEMPERATURES</td> <td>Press to open the TEMPERATURES screen</td> </tr> </table> <p>DATA</p> <table border="1" data-bbox="844 420 1404 588"> <tr> <td>VOLTAGE</td> <td>Voltage measured by Instrument</td> </tr> <tr> <td>V PHASE</td> <td>Voltage phase angle with respect to reference frame</td> </tr> <tr> <td>CURRENT</td> <td>Current measured by Instrument</td> </tr> <tr> <td>I PHASE</td> <td>Current phase angle with respect to A phase voltage</td> </tr> </table> <p>3.3.3.3 TEMPERATURES</p> <p>This screen displays temperatures of internal circuit boards.</p> <p>FUNCTION KEYS</p> <table border="1" data-bbox="844 808 1404 861"> <tr> <td>BACK</td> <td>Press to return to the DRIVE ACTIVE screen</td> </tr> </table>	TEMPERATURES	Press to open the TEMPERATURES screen	VOLTAGE	Voltage measured by Instrument	V PHASE	Voltage phase angle with respect to reference frame	CURRENT	Current measured by Instrument	I PHASE	Current phase angle with respect to A phase voltage	BACK	Press to return to the DRIVE ACTIVE screen																										
TEMPERATURES	Press to open the TEMPERATURES screen																																						
VOLTAGE	Voltage measured by Instrument																																						
V PHASE	Voltage phase angle with respect to reference frame																																						
CURRENT	Current measured by Instrument																																						
I PHASE	Current phase angle with respect to A phase voltage																																						
BACK	Press to return to the DRIVE ACTIVE screen																																						
<p style="text-align: center;">UNIT TEST / METER INFO</p>  <p style="text-align: center;">SINGLE TEST SETUP / SEQUENCE SETUP</p>	<p>3.3.3.4 METER INFO SOCKET</p> <p>This screen allows the user to enter new meter information.</p> <p>NOTE: Data entry is available only when meter is inserted in socket.</p> <p>FUNCTION KEYS</p> <table border="1" data-bbox="844 1029 1404 1228"> <tr> <td>CANCEL</td> <td>Returns to the previous screen.</td> </tr> <tr> <td>DONE</td> <td>Saves changes and proceeds to the either of the following: <ul style="list-style-type: none"> - SEQUENCE SETUP (when performing SEQUENCE TESTING) - SINGLE TEST SETUP (when performing MANUAL TEST) </td> </tr> </table> <p>DATA</p> <table border="1" data-bbox="844 1260 1404 1858"> <tr> <td>SERIAL #</td> <td>Serial number of the meter</td> </tr> <tr> <td>MANUFCT.</td> <td>Manufacturer's name</td> </tr> <tr> <td>MODEL #</td> <td>Model number of the meter</td> </tr> <tr> <td>CATALOG #</td> <td>Catalog # of the meter</td> </tr> <tr> <td>UTILITY S/N</td> <td>Serial number provided by Utility (if applicable)</td> </tr> <tr> <td>COMM S/N</td> <td>Serial number of communication device (if applicable)</td> </tr> <tr> <td>FORM</td> <td>Form number of the meter (auto-populates the default Kh in the Kh field)</td> </tr> <tr> <td>BASE</td> <td>Meter base (S, K, A, etc...)</td> </tr> <tr> <td>CLASS</td> <td>Meter class (determines maximum current and auto-populates the default test amps in TA field)</td> </tr> <tr> <td>TA</td> <td>Test Amps (RMS of a full load test)</td> </tr> <tr> <td>Kh</td> <td>Watt hours per revolution of disk</td> </tr> <tr> <td>Kt</td> <td>Watt hours per pulse</td> </tr> <tr> <td>Pulses Per Rev</td> <td>Number of pulses in every revolution of the disk. Integer >= 1</td> </tr> <tr> <td>Accuracy Class</td> <td>Accuracy of the meter</td> </tr> <tr> <td>DEMAND</td> <td>Select if meter has demand functionality</td> </tr> <tr> <td>KYZ</td> <td>Select if meter has KYZ functionality</td> </tr> <tr> <td>BIDERCTIONAL</td> <td>Select if meter has bidirectionality functionality</td> </tr> </table>	CANCEL	Returns to the previous screen.	DONE	Saves changes and proceeds to the either of the following: <ul style="list-style-type: none"> - SEQUENCE SETUP (when performing SEQUENCE TESTING) - SINGLE TEST SETUP (when performing MANUAL TEST) 	SERIAL #	Serial number of the meter	MANUFCT.	Manufacturer's name	MODEL #	Model number of the meter	CATALOG #	Catalog # of the meter	UTILITY S/N	Serial number provided by Utility (if applicable)	COMM S/N	Serial number of communication device (if applicable)	FORM	Form number of the meter (auto-populates the default Kh in the Kh field)	BASE	Meter base (S, K, A, etc...)	CLASS	Meter class (determines maximum current and auto-populates the default test amps in TA field)	TA	Test Amps (RMS of a full load test)	Kh	Watt hours per revolution of disk	Kt	Watt hours per pulse	Pulses Per Rev	Number of pulses in every revolution of the disk. Integer >= 1	Accuracy Class	Accuracy of the meter	DEMAND	Select if meter has demand functionality	KYZ	Select if meter has KYZ functionality	BIDERCTIONAL	Select if meter has bidirectionality functionality
CANCEL	Returns to the previous screen.																																						
DONE	Saves changes and proceeds to the either of the following: <ul style="list-style-type: none"> - SEQUENCE SETUP (when performing SEQUENCE TESTING) - SINGLE TEST SETUP (when performing MANUAL TEST) 																																						
SERIAL #	Serial number of the meter																																						
MANUFCT.	Manufacturer's name																																						
MODEL #	Model number of the meter																																						
CATALOG #	Catalog # of the meter																																						
UTILITY S/N	Serial number provided by Utility (if applicable)																																						
COMM S/N	Serial number of communication device (if applicable)																																						
FORM	Form number of the meter (auto-populates the default Kh in the Kh field)																																						
BASE	Meter base (S, K, A, etc...)																																						
CLASS	Meter class (determines maximum current and auto-populates the default test amps in TA field)																																						
TA	Test Amps (RMS of a full load test)																																						
Kh	Watt hours per revolution of disk																																						
Kt	Watt hours per pulse																																						
Pulses Per Rev	Number of pulses in every revolution of the disk. Integer >= 1																																						
Accuracy Class	Accuracy of the meter																																						
DEMAND	Select if meter has demand functionality																																						
KYZ	Select if meter has KYZ functionality																																						
BIDERCTIONAL	Select if meter has bidirectionality functionality																																						


3.3.3 SINGLE TEST SETUP

SCREEN	DESCRIPTION																																								
<p>The screenshots illustrate the configuration steps for a single test. In the first, 'Accuracy' is selected and the 'DRIVE OFF' indicator is lit. In the second, 'TimeRun' or 'TimedReg' is selected. In the third, 'Demand' is selected. The final step is the 'PULSE ALIGNMENT CHECK' screen, which shows a pulse count of 0 and a 'DONE' button.</p>	<h4>3.3.4.1 SINGLE TEST SETUP</h4> <p>This enables the configuration of the desired single test to be conducted.</p> <p>FUNCTION KEYS</p> <table border="1"> <tr> <td>VOLTAGE ON</td> <td>Press to enable service voltage to the socket</td> </tr> <tr> <td>PULSE ALIGN</td> <td>Press to align optical pickup. Refer to §3.4 for additional information on this feature.</td> </tr> <tr> <td>METER INFO</td> <td>Press to return to the METER INFO screen</td> </tr> <tr> <td>BEGIN</td> <td>Press to open SEQUENCE ACTIVE screen</td> </tr> </table> <p>DATA</p> <table border="1"> <thead> <tr> <th rowspan="4">TEST TYPE</th> <th>Accuracy</th> <td>Performs accuracy test</td> </tr> <tr> <th>TimeRun</th> <td>Performs test with a predefined duration</td> </tr> <tr> <th>TimedReg</th> <td>Prompts the user for the meter's measured register, runs a test for a predefined duration. Then prompts the user for the meter register again and uses that as meter's measured power.</td> </tr> <tr> <th>Demand</th> <td>Runs a demand test</td> </tr> </thead> <tbody> <tr> <td>PULSES/REVS</td> <td colspan="2">Enables counting of pulses</td> </tr> <tr> <td>DURATION</td> <td colspan="2">Enables setting the test duration</td> </tr> <tr> <td>INTERVAL</td> <td colspan="2">Enables setting the interval of meter</td> </tr> <tr> <td>SUB-IN</td> <td colspan="2">Enables setting the sub interval for the demand test</td> </tr> <tr> <td>ITERATIONS</td> <td colspan="2">Number of times the test will be repeated</td> </tr> <tr> <td>TOLERANCE</td> <td colspan="2">Tolerance needed for pass/fail criteria</td> </tr> <tr> <td>WARM-UP</td> <td colspan="2">Period of time for meter to stabilize prior to test execution</td> </tr> </tbody> </table> <p>WARNING: If either VOLTAGE ON or LOAD ON is enabled, the indicator will change to . This indicates there is potential and/or current present at the meter terminals.</p> <h4>3.3.4.2 PULSE ALIGNMENT CHECK</h4> <p>This will apply voltage and current to the meter, so that the optical probe can be aligned with the meter's pulse output.</p> <p>FUNCTION KEYS</p> <table border="1"> <tr> <td>DONE</td> <td>Press to close the PULSE ALIGN CHECK dialog box</td> </tr> </table>	VOLTAGE ON	Press to enable service voltage to the socket	PULSE ALIGN	Press to align optical pickup. Refer to §3.4 for additional information on this feature.	METER INFO	Press to return to the METER INFO screen	BEGIN	Press to open SEQUENCE ACTIVE screen	TEST TYPE	Accuracy	Performs accuracy test	TimeRun	Performs test with a predefined duration	TimedReg	Prompts the user for the meter's measured register, runs a test for a predefined duration. Then prompts the user for the meter register again and uses that as meter's measured power.	Demand	Runs a demand test	PULSES/REVS	Enables counting of pulses		DURATION	Enables setting the test duration		INTERVAL	Enables setting the interval of meter		SUB-IN	Enables setting the sub interval for the demand test		ITERATIONS	Number of times the test will be repeated		TOLERANCE	Tolerance needed for pass/fail criteria		WARM-UP	Period of time for meter to stabilize prior to test execution		DONE	Press to close the PULSE ALIGN CHECK dialog box
VOLTAGE ON	Press to enable service voltage to the socket																																								
PULSE ALIGN	Press to align optical pickup. Refer to §3.4 for additional information on this feature.																																								
METER INFO	Press to return to the METER INFO screen																																								
BEGIN	Press to open SEQUENCE ACTIVE screen																																								
TEST TYPE	Accuracy	Performs accuracy test																																							
	TimeRun	Performs test with a predefined duration																																							
	TimedReg	Prompts the user for the meter's measured register, runs a test for a predefined duration. Then prompts the user for the meter register again and uses that as meter's measured power.																																							
	Demand	Runs a demand test																																							
PULSES/REVS	Enables counting of pulses																																								
DURATION	Enables setting the test duration																																								
INTERVAL	Enables setting the interval of meter																																								
SUB-IN	Enables setting the sub interval for the demand test																																								
ITERATIONS	Number of times the test will be repeated																																								
TOLERANCE	Tolerance needed for pass/fail criteria																																								
WARM-UP	Period of time for meter to stabilize prior to test execution																																								
DONE	Press to close the PULSE ALIGN CHECK dialog box																																								

3.3.4 TEST SELECTION


SCREEN	DESCRIPTION									
	<p>3.3.5.1 TESTS</p> <p>The TEST SELECTION screen consists of the following function buttons: MANUAL, PLC, & DISCONNECT. Press arrow keys to navigate through the menu or directly press the function keys.</p> <p>KEYPAD & FUNCTION KEYS:</p> <table border="1" data-bbox="881 499 1484 653"> <tr> <td>F1</td> <td>SEQUENCE</td> <td>Press to open METER INFO screen. Refer to §3.3.3.4 for additional info.</td> </tr> <tr> <td>F3</td> <td>PLC</td> <td>Press to open the PLC TEST screen</td> </tr> <tr> <td>F4</td> <td>DISCONNECT</td> <td>Press to open the DISCONNECT TEST screen</td> </tr> </table>	F1	SEQUENCE	Press to open METER INFO screen. Refer to §3.3.3.4 for additional info.	F3	PLC	Press to open the PLC TEST screen	F4	DISCONNECT	Press to open the DISCONNECT TEST screen
F1	SEQUENCE	Press to open METER INFO screen. Refer to §3.3.3.4 for additional info.								
F3	PLC	Press to open the PLC TEST screen								
F4	DISCONNECT	Press to open the DISCONNECT TEST screen								

3.3.5 SEQUENCE TESTING


SCREEN	DESCRIPTION																										
	<p>3.3.6.1 SEQUENCE SETUP</p> <p>This enables the selection of the desired test sequence to be conducted. To change FORM and SERVICE, return to METER INFORMATION.</p> <p>KEYPAD & FUNCTION KEYS</p> <table border="1" data-bbox="881 1098 1450 1297"> <tr> <td>VOLTAGE ON</td> <td>Press to enable service voltage to the socket</td> </tr> <tr> <td>PULSE ALIGN</td> <td>Press to enter pulse alignment mode and show the number of pulses from the meter.</td> </tr> <tr> <td>METER INFO</td> <td>Press to return to the METER INFO screen</td> </tr> <tr> <td>BEGIN</td> <td>Starts the sequence test.</td> </tr> </table> <p>DATA</p> <table border="1" data-bbox="881 1350 1450 1703"> <tr> <td>FORM</td> <td>Form number of the meter (auto-populates the default Kh in the Kh field)</td> </tr> <tr> <td>SERVICE</td> <td>Services available for selected meter form</td> </tr> <tr> <td>SEQUENCE</td> <td>Sequences available for selected meter form</td> </tr> <tr> <td>EN A</td> <td>Toggle to enable or disable a test selection</td> </tr> <tr> <td>TAG</td> <td>Alias or brief description of the test</td> </tr> <tr> <td>MODE</td> <td>Type of test</td> </tr> <tr> <td>WAVEFORM SETUP</td> <td>Waveform setup of the test</td> </tr> <tr> <td>Time/Puls/Revs</td> <td>Input time, pulses, or revolutions for selected test type</td> </tr> <tr> <td># of Tests</td> <td>Number of times the test will be repeated</td> </tr> </table>	VOLTAGE ON	Press to enable service voltage to the socket	PULSE ALIGN	Press to enter pulse alignment mode and show the number of pulses from the meter.	METER INFO	Press to return to the METER INFO screen	BEGIN	Starts the sequence test.	FORM	Form number of the meter (auto-populates the default Kh in the Kh field)	SERVICE	Services available for selected meter form	SEQUENCE	Sequences available for selected meter form	EN A	Toggle to enable or disable a test selection	TAG	Alias or brief description of the test	MODE	Type of test	WAVEFORM SETUP	Waveform setup of the test	Time/Puls/Revs	Input time, pulses, or revolutions for selected test type	# of Tests	Number of times the test will be repeated
VOLTAGE ON	Press to enable service voltage to the socket																										
PULSE ALIGN	Press to enter pulse alignment mode and show the number of pulses from the meter.																										
METER INFO	Press to return to the METER INFO screen																										
BEGIN	Starts the sequence test.																										
FORM	Form number of the meter (auto-populates the default Kh in the Kh field)																										
SERVICE	Services available for selected meter form																										
SEQUENCE	Sequences available for selected meter form																										
EN A	Toggle to enable or disable a test selection																										
TAG	Alias or brief description of the test																										
MODE	Type of test																										
WAVEFORM SETUP	Waveform setup of the test																										
Time/Puls/Revs	Input time, pulses, or revolutions for selected test type																										
# of Tests	Number of times the test will be repeated																										

SCREEN	DESCRIPTION																																																							
<div style="text-align: center; margin-bottom: 10px;"> SEQUENCE SETUP </div> <div style="margin-bottom: 10px;"> </div> <div style="margin-bottom: 10px;"> </div> <div style="margin-bottom: 10px;"> </div> <div style="margin-bottom: 10px;"> </div> <div> </div>	<h3>3.3.6.3 SEQUENCE ACTIVE</h3> <p>This screen shows the live results of the tests.</p> <p>KEYPAD & FUNCTION KEYS</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 150px;">CANCEL</td> <td>Press to cancel the test process and return to SEQUENCE SETUP screen</td> </tr> <tr> <td style="text-align: center;">INT</td> <td>Press to open the MEASUREMENTS screen</td> </tr> <tr> <td style="text-align: center;">RESULTS</td> <td>Press to show test results</td> </tr> <tr> <td style="text-align: center;">SKIP</td> <td>Press to skip the ongoing test and proceed to the next test in the sequence</td> </tr> </table> <p>DATA</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>SEQUENCE</td><td>Current test sequence</td></tr> <tr><td>TEST #</td><td>Current test number in sequence</td></tr> <tr><td>ITERATION</td><td>Current repeat of test number</td></tr> <tr><td>TAG</td><td>Alias or brief description of the test</td></tr> <tr><td>PRESET</td><td>Pulse required</td></tr> <tr><td>ACTUAL</td><td>Pulse count</td></tr> <tr><td>REMAINING</td><td>Pulse remaining</td></tr> <tr><td>WH</td><td>Measured real energy</td></tr> <tr><td>VARH</td><td>Measured reactive energy</td></tr> <tr><td>VAH</td><td>Measured apparent energy</td></tr> </table> <h3>3.3.6.4 TEST RESULTS</h3> <p>This screen shows the results and it can be accessed during a test.</p> <p>KEYPAD & FUNCTION KEYS:</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 100px;">F1</td> <td style="text-align: center; width: 100px;">BACK</td> <td>Press to return to: - SEQUENCE ACTIVE screen (during a test) - SEQUENCE SETUP screen (when tests complete)</td> </tr> <tr> <td style="text-align: center;">F3</td> <td style="text-align: center;">PREV RESULT</td> <td>Press to show the previous test result</td> </tr> <tr> <td style="text-align: center;">F4</td> <td style="text-align: center;">NEXT RESULT</td> <td>Press to show the next test result</td> </tr> </table> <p>DATA</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>SEQUENCE</td><td>Current test sequence</td></tr> <tr><td>TEST#</td><td>Current test number in sequence</td></tr> <tr><td>ITERATION#</td><td>Current repeat of test number</td></tr> <tr><td>TAG</td><td>Alias or brief description of the test</td></tr> <tr><td>WH</td><td>Measured real energy</td></tr> <tr><td>VARH</td><td>Measured reactive energy</td></tr> <tr><td>VAH</td><td>Measured apparent energy</td></tr> <tr><td>%ERR</td><td>Percentage error</td></tr> <tr><td>REG</td><td>Percent registration</td></tr> </table>	CANCEL	Press to cancel the test process and return to SEQUENCE SETUP screen	INT	Press to open the MEASUREMENTS screen	RESULTS	Press to show test results	SKIP	Press to skip the ongoing test and proceed to the next test in the sequence	SEQUENCE	Current test sequence	TEST #	Current test number in sequence	ITERATION	Current repeat of test number	TAG	Alias or brief description of the test	PRESET	Pulse required	ACTUAL	Pulse count	REMAINING	Pulse remaining	WH	Measured real energy	VARH	Measured reactive energy	VAH	Measured apparent energy	F1	BACK	Press to return to: - SEQUENCE ACTIVE screen (during a test) - SEQUENCE SETUP screen (when tests complete)	F3	PREV RESULT	Press to show the previous test result	F4	NEXT RESULT	Press to show the next test result	SEQUENCE	Current test sequence	TEST#	Current test number in sequence	ITERATION#	Current repeat of test number	TAG	Alias or brief description of the test	WH	Measured real energy	VARH	Measured reactive energy	VAH	Measured apparent energy	%ERR	Percentage error	REG	Percent registration
CANCEL	Press to cancel the test process and return to SEQUENCE SETUP screen																																																							
INT	Press to open the MEASUREMENTS screen																																																							
RESULTS	Press to show test results																																																							
SKIP	Press to skip the ongoing test and proceed to the next test in the sequence																																																							
SEQUENCE	Current test sequence																																																							
TEST #	Current test number in sequence																																																							
ITERATION	Current repeat of test number																																																							
TAG	Alias or brief description of the test																																																							
PRESET	Pulse required																																																							
ACTUAL	Pulse count																																																							
REMAINING	Pulse remaining																																																							
WH	Measured real energy																																																							
VARH	Measured reactive energy																																																							
VAH	Measured apparent energy																																																							
F1	BACK	Press to return to: - SEQUENCE ACTIVE screen (during a test) - SEQUENCE SETUP screen (when tests complete)																																																						
F3	PREV RESULT	Press to show the previous test result																																																						
F4	NEXT RESULT	Press to show the next test result																																																						
SEQUENCE	Current test sequence																																																							
TEST#	Current test number in sequence																																																							
ITERATION#	Current repeat of test number																																																							
TAG	Alias or brief description of the test																																																							
WH	Measured real energy																																																							
VARH	Measured reactive energy																																																							
VAH	Measured apparent energy																																																							
%ERR	Percentage error																																																							
REG	Percent registration																																																							



3.3.6 PLC TEST

SCREEN	DESCRIPTION																				
	<p>3.3.7.1 PLC TEST</p> <p>PLC or Power Line Carrier test is for testing wired communication systems such as TWACS, etc. It bypasses the internal voltage and generation circuits.</p> <p>KEYPAD & FUNCTION KEYS</p> <table border="1"> <tr> <td>VOLTAGE ON</td> <td>Press to enable service voltage only to socket</td> </tr> <tr> <td>LOAD ON</td> <td>Press to enable service voltage and load current to socket</td> </tr> </table> <p>When power is enabled, the control buttons adjust accordingly</p> <table border="1"> <tr> <td>VOLTAGE OFF</td> <td>Press to disable voltage and current to socket</td> </tr> <tr> <td>LOAD OFF</td> <td>Press to disable current only to socket Service voltage will remain enabled</td> </tr> </table> <p>DATA</p> <table border="1"> <tr> <td>FORM</td> <td>Form number of the meter</td> </tr> <tr> <td>VOLTAGE</td> <td>Select voltage value</td> </tr> <tr> <td>SET CURRENT</td> <td>Current set by the user</td> </tr> <tr> <td>LOAD</td> <td>Displays either of the following status: <ul style="list-style-type: none"> • OFF – no current is flowing • ON – current is flowing </td> </tr> <tr> <td>MEASURED V</td> <td>Measured voltage</td> </tr> <tr> <td>MEASURED I</td> <td>Measured current</td> </tr> </table>	VOLTAGE ON	Press to enable service voltage only to socket	LOAD ON	Press to enable service voltage and load current to socket	VOLTAGE OFF	Press to disable voltage and current to socket	LOAD OFF	Press to disable current only to socket Service voltage will remain enabled	FORM	Form number of the meter	VOLTAGE	Select voltage value	SET CURRENT	Current set by the user	LOAD	Displays either of the following status: <ul style="list-style-type: none"> • OFF – no current is flowing • ON – current is flowing 	MEASURED V	Measured voltage	MEASURED I	Measured current
VOLTAGE ON	Press to enable service voltage only to socket																				
LOAD ON	Press to enable service voltage and load current to socket																				
VOLTAGE OFF	Press to disable voltage and current to socket																				
LOAD OFF	Press to disable current only to socket Service voltage will remain enabled																				
FORM	Form number of the meter																				
VOLTAGE	Select voltage value																				
SET CURRENT	Current set by the user																				
LOAD	Displays either of the following status: <ul style="list-style-type: none"> • OFF – no current is flowing • ON – current is flowing 																				
MEASURED V	Measured voltage																				
MEASURED I	Measured current																				


3.3.7 DISCONNECT TEST


SCREEN	DESCRIPTION																						
	<p>3.3.8.1 DISCONNECT TEST</p> <p>Disconnect testing is used for testing meters with built-in disconnect contacts. This test can only be performed on 1S, 2S, or 12S meters.</p> <p>KEYPAD & FUNCTION KEYS</p> <table border="1"> <tr> <td>VOLTAGE ON</td> <td>Enables voltage, back voltage, and current</td> </tr> <tr> <td>ENABLE BV.</td> <td>Enables back voltage</td> </tr> <tr> <td>LOAD ON</td> <td>Applies back voltage and current to the socket</td> </tr> </table> <p>When the buttons are turned on, the user can also switch them off:</p> <table border="1"> <tr> <td>VOLTAGE OFF</td> <td>Disables voltage, back voltage, and current</td> </tr> <tr> <td>LOAD OFF</td> <td>Disables current only. Voltage remains enabled.</td> </tr> </table> <p>DATA</p> <table border="1"> <tr> <td>FORM</td> <td>Form number of the meter</td> </tr> <tr> <td>VOLTAGE</td> <td>Voltage applied to meter</td> </tr> <tr> <td>SET CURRENT</td> <td>Current set by the user</td> </tr> <tr> <td>BACKVOLTAGE</td> <td>Back voltage status: ON or OFF</td> </tr> <tr> <td>LOAD</td> <td>Load status: ON or OFF</td> </tr> <tr> <td>MEASURED I</td> <td>Measured current</td> </tr> </table>	VOLTAGE ON	Enables voltage, back voltage, and current	ENABLE BV.	Enables back voltage	LOAD ON	Applies back voltage and current to the socket	VOLTAGE OFF	Disables voltage, back voltage, and current	LOAD OFF	Disables current only. Voltage remains enabled.	FORM	Form number of the meter	VOLTAGE	Voltage applied to meter	SET CURRENT	Current set by the user	BACKVOLTAGE	Back voltage status: ON or OFF	LOAD	Load status: ON or OFF	MEASURED I	Measured current
VOLTAGE ON	Enables voltage, back voltage, and current																						
ENABLE BV.	Enables back voltage																						
LOAD ON	Applies back voltage and current to the socket																						
VOLTAGE OFF	Disables voltage, back voltage, and current																						
LOAD OFF	Disables current only. Voltage remains enabled.																						
FORM	Form number of the meter																						
VOLTAGE	Voltage applied to meter																						
SET CURRENT	Current set by the user																						
BACKVOLTAGE	Back voltage status: ON or OFF																						
LOAD	Load status: ON or OFF																						
MEASURED I	Measured current																						

3.3.8 TIME & USER INFORMATION


SCREEN	DESCRIPTION																	
 <p>The screenshot shows the 'SETUP MENU' with three main options: TIME, USER, and SYSTEM. The 'TIME' option is highlighted with a red box. Red arrows indicate the flow from the 'TIME' icon to the 'TIME' screen, from the 'USER' icon to the 'USER INFORMATION' screen, and from the 'SYSTEM' icon to the 'SYSTEM INFORMATION' screen.</p>	<p>3.3.9.1 SETUP MENU</p> <p>The SETUP MENU screen consists of the following function buttons: TIME, USER, and SYSTEM. Press arrow keys to navigate through the main menu or directly press the function keys.</p> <p>KEYPAD & FUNCTION KEYS:</p> <table border="1" data-bbox="876 598 1453 777"> <tr> <td>F1</td> <td>TIME</td> <td>Press TIME to open the TIME screen</td> </tr> <tr> <td>F2</td> <td>USER</td> <td>Press USER to open the USER INFORMATION screen</td> </tr> <tr> <td>F4</td> <td>SYSTEM</td> <td>Press SYSTEM to open the SYSTEM INFORMATION screen</td> </tr> </table> <p>3.3.9.2 TIME</p> <p>FUNCTION KEYS</p> <table border="1" data-bbox="876 924 1453 987"> <tr> <td>BEEP</td> <td>Press to enable currently configured audible signal</td> </tr> </table> <p>DATA</p> <table border="1" data-bbox="876 1039 1453 1176"> <tr> <td>TIME</td> <td>This will be set automatically when connected to a DHCP server</td> </tr> <tr> <td>DATE</td> <td>This will be set automatically when connected to a DHCP server</td> </tr> <tr> <td>TIME ZONE</td> <td>Enter local time zone here</td> </tr> </table>	F1	TIME	Press TIME to open the TIME screen	F2	USER	Press USER to open the USER INFORMATION screen	F4	SYSTEM	Press SYSTEM to open the SYSTEM INFORMATION screen	BEEP	Press to enable currently configured audible signal	TIME	This will be set automatically when connected to a DHCP server	DATE	This will be set automatically when connected to a DHCP server	TIME ZONE	Enter local time zone here
F1	TIME	Press TIME to open the TIME screen																
F2	USER	Press USER to open the USER INFORMATION screen																
F4	SYSTEM	Press SYSTEM to open the SYSTEM INFORMATION screen																
BEEP	Press to enable currently configured audible signal																	
TIME	This will be set automatically when connected to a DHCP server																	
DATE	This will be set automatically when connected to a DHCP server																	
TIME ZONE	Enter local time zone here																	
 <p>The screenshot shows the 'USER INFORMATION' screen with a 'USER' field containing the text 'Tesco'. A red arrow points from the 'USER INFORMATION' title to the 'USER' field.</p>	<p>3.3.9.3 USER INFORMATION</p> <p>The default user name is "Tesco". This can only be updated through TMA software.</p> <p>KEYPAD & FUNCTION KEYS:</p> <table border="1" data-bbox="876 1449 1453 1501"> <tr> <td>BACK</td> <td>Press to return to SETUP MENU screen</td> </tr> </table> <p>DATA</p> <table border="1" data-bbox="876 1554 1453 1606"> <tr> <td>USER</td> <td>Name of the user logged in through the Test Manager Application (TMA)</td> </tr> </table>	BACK	Press to return to SETUP MENU screen	USER	Name of the user logged in through the Test Manager Application (TMA)													
BACK	Press to return to SETUP MENU screen																	
USER	Name of the user logged in through the Test Manager Application (TMA)																	

3.3.9 SYSTEM INFORMATION

SCREEN	DESCRIPTION																																														
<div style="text-align: center; margin-bottom: 10px;"> SYSTEM INFORMATION </div>  <div style="text-align: center; margin-bottom: 10px;"> SYSTEM INFORMATION (CONTROLLERS) </div>	<p>3.3.10.1 SYSTEM INFORMATION</p> <p>This screen displays information about the hardware configurations, firmware revision levels and network configuration</p> <p>SYSTEM/MODULE INFORMATION TAB</p> <p>KEYPAD &FUNCTION KEYS</p> <table border="1" data-bbox="881 468 1450 573"> <tr> <td style="text-align: center;">NEXT</td> <td>Press to open the STANDARD INFORMATION tab</td> </tr> <tr> <td style="text-align: center;">NETWORK</td> <td>Press to open the NETWORK SETUP dialog box</td> </tr> </table> <p>DATA</p> <table border="1" data-bbox="881 617 1456 909"> <tr> <td rowspan="3" style="text-align: center;">SYSTEM</td> <td style="text-align: center;">PRODUCT</td> <td>Product name of the device</td> </tr> <tr> <td style="text-align: center;">SERIAL #</td> <td>Serial number of the device</td> </tr> <tr> <td style="text-align: center;">HW VER</td> <td>Hardware version of the device</td> </tr> <tr> <td rowspan="3" style="text-align: center;">MODULE</td> <td style="text-align: center;">NAME</td> <td>Displays the name of the system. Can be updated by the user through TMA</td> </tr> <tr> <td style="text-align: center;">MODEL</td> <td>Displays the model name of the device</td> </tr> <tr> <td style="text-align: center;">SERIAL #</td> <td>Displays the serial number of the device</td> </tr> </table> <p>STANDARD INFORMATION TAB</p> <p>KEYPAD &FUNCTION KEYS</p> <table border="1" data-bbox="881 993 1450 1098"> <tr> <td style="text-align: center;">NEXT</td> <td>Press to open the WAVEFORM GENERATOR tab</td> </tr> <tr> <td style="text-align: center;">NETWORK</td> <td>Press to open the NETWORK SETUP dialog box</td> </tr> </table> <p>DATA</p> <table border="1" data-bbox="881 1136 1446 1276"> <tr> <td style="text-align: center;">BOARD</td> <td>Displays the physical board type</td> </tr> <tr> <td style="text-align: center;">SERIAL #</td> <td>Displays the serial number of the board</td> </tr> <tr> <td style="text-align: center;">HW REV</td> <td>Displays the HW rev of the board</td> </tr> <tr> <td style="text-align: center;">FPGA VER</td> <td>Displays the FPGA binary version</td> </tr> <tr> <td style="text-align: center;">SOFTWARE</td> <td>Displays the application SW version</td> </tr> </table> <p>WAVEFORM GENERATOR TAB</p> <p>KEYPAD &FUNCTION KEYS</p> <table border="1" data-bbox="881 1423 1450 1528"> <tr> <td style="text-align: center;">NEXT</td> <td>Proceeds to the CONTROLLERS tab.</td> </tr> <tr> <td style="text-align: center;">NETWORK</td> <td>Press to open the NETWORK SETUP dialog box</td> </tr> </table> <p>DATA</p> <table border="1" data-bbox="881 1566 1446 1707"> <tr> <td style="text-align: center;">BOARD</td> <td>Displays the physical board type</td> </tr> <tr> <td style="text-align: center;">SERIAL #</td> <td>Displays the serial number of the board</td> </tr> <tr> <td style="text-align: center;">HW REV</td> <td>Displays the HW rev of the board</td> </tr> <tr> <td style="text-align: center;">FPGA VER</td> <td>Displays the FPGA binary version</td> </tr> <tr> <td style="text-align: center;">SOFTWARE</td> <td>Displays the application SW version</td> </tr> </table>	NEXT	Press to open the STANDARD INFORMATION tab	NETWORK	Press to open the NETWORK SETUP dialog box	SYSTEM	PRODUCT	Product name of the device	SERIAL #	Serial number of the device	HW VER	Hardware version of the device	MODULE	NAME	Displays the name of the system. Can be updated by the user through TMA	MODEL	Displays the model name of the device	SERIAL #	Displays the serial number of the device	NEXT	Press to open the WAVEFORM GENERATOR tab	NETWORK	Press to open the NETWORK SETUP dialog box	BOARD	Displays the physical board type	SERIAL #	Displays the serial number of the board	HW REV	Displays the HW rev of the board	FPGA VER	Displays the FPGA binary version	SOFTWARE	Displays the application SW version	NEXT	Proceeds to the CONTROLLERS tab.	NETWORK	Press to open the NETWORK SETUP dialog box	BOARD	Displays the physical board type	SERIAL #	Displays the serial number of the board	HW REV	Displays the HW rev of the board	FPGA VER	Displays the FPGA binary version	SOFTWARE	Displays the application SW version
NEXT	Press to open the STANDARD INFORMATION tab																																														
NETWORK	Press to open the NETWORK SETUP dialog box																																														
SYSTEM	PRODUCT	Product name of the device																																													
	SERIAL #	Serial number of the device																																													
	HW VER	Hardware version of the device																																													
MODULE	NAME	Displays the name of the system. Can be updated by the user through TMA																																													
	MODEL	Displays the model name of the device																																													
	SERIAL #	Displays the serial number of the device																																													
NEXT	Press to open the WAVEFORM GENERATOR tab																																														
NETWORK	Press to open the NETWORK SETUP dialog box																																														
BOARD	Displays the physical board type																																														
SERIAL #	Displays the serial number of the board																																														
HW REV	Displays the HW rev of the board																																														
FPGA VER	Displays the FPGA binary version																																														
SOFTWARE	Displays the application SW version																																														
NEXT	Proceeds to the CONTROLLERS tab.																																														
NETWORK	Press to open the NETWORK SETUP dialog box																																														
BOARD	Displays the physical board type																																														
SERIAL #	Displays the serial number of the board																																														
HW REV	Displays the HW rev of the board																																														
FPGA VER	Displays the FPGA binary version																																														
SOFTWARE	Displays the application SW version																																														

<div style="text-align: center; margin-bottom: 10px;"> <div style="background-color: red; color: white; padding: 5px; display: inline-block; border-radius: 10px;"> SYSTEM INFORMATION (WAVEFORM GENERATOR) </div>  </div>	<p>CONTROLLERS TAB</p> <p>KEYPAD & FUNCTION KEYS</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 150px;">NEXT</td> <td>Proceeds to the SYSTEM INFORMATION tab</td> </tr> <tr> <td style="text-align: center;">NETWORK</td> <td>Press to open the NETWORK SETUP dialog box</td> </tr> </table> <p>DATA</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 150px;">SOCKET 1</td> <td>Displays the serial number and software version of the socket</td> </tr> </table>	NEXT	Proceeds to the SYSTEM INFORMATION tab	NETWORK	Press to open the NETWORK SETUP dialog box	SOCKET 1	Displays the serial number and software version of the socket
NEXT	Proceeds to the SYSTEM INFORMATION tab						
NETWORK	Press to open the NETWORK SETUP dialog box						
SOCKET 1	Displays the serial number and software version of the socket						

3.3.10 NETWORK SETUP

SCREEN	DESCRIPTION										
<div style="text-align: center; margin-bottom: 10px;"> <div style="background-color: red; color: white; padding: 5px; display: inline-block; border-radius: 10px;"> NETWORK SETUP </div>  </div>	<p>3.3.11.1 NETWORK SETUP</p> <p>Display and edit required network settings.</p> <p>KEYPAD & FUNCTION KEYS</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 150px;">APPLY</td> <td>Press to apply current configuration without closing network dialog box</td> </tr> <tr> <td style="text-align: center;">CANCEL</td> <td>Press to close dialog box without saving changes</td> </tr> <tr> <td style="text-align: center;">ENTER</td> <td>Press to save current configuration and close dialog box</td> </tr> </table> <p>DATA</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 150px;">STATIC IP</td> <td>Select for user specified IP address</td> </tr> <tr> <td style="text-align: center;">DHCP</td> <td>Select for network assigned IP address</td> </tr> </table>	APPLY	Press to apply current configuration without closing network dialog box	CANCEL	Press to close dialog box without saving changes	ENTER	Press to save current configuration and close dialog box	STATIC IP	Select for user specified IP address	DHCP	Select for network assigned IP address
APPLY	Press to apply current configuration without closing network dialog box										
CANCEL	Press to close dialog box without saving changes										
ENTER	Press to save current configuration and close dialog box										
STATIC IP	Select for user specified IP address										
DHCP	Select for network assigned IP address										

3.4 Optical Pickup Alignment

Plug the optical pickup into the OPTICAL PICKUP port. Mount the meter into the socket and attach magnetic optical pickup to optical port of meter. For meter insertion and extraction, refer to section **2.5 Utility Meter Insertion/Extraction**.

To remove the optical pickup, hold it by the body and gently pull away from the meter. There is an indicator light showing that the pickup has power. If alignment is difficult to achieve, the PULSE ALIGN feature is available to assist with alignment.

4.0 REMOTE OPERATIONS

- 4.1 Introduction 24**
- 4.2 Installation 24**
- 4.3 Network Configuration 24**
- 4.4 Functionalities 24**
 - 4.4.1 NETWORK VIEW 24
 - 4.4.2 METER TEST 25
 - 4.4.3 METER DATABASE 25
 - 4.4.5 TEST SEQUENCE 25
 - 4.4.6 MANUAL SETUP 26

4.1 Introduction

This chapter provides a brief introduction on how to remotely operate the Instrument, conduct test, and manage information using Test Manager Application (TMA). Additional information can be found on certain sections in the TMA Operations Manual.

4.2 Installation

In the installation, only **TMA_Setup.exe** is needed. Please refer to Section **1.2 The Installation** in the TMA Operations Manual for instructions.

4.3 Network Configuration

Remote access requires establishing the connection between the Instrument and TMA. Please refer to Section **1.3 Configuring the TMA Software** in the TMA Operations Manual for instructions.


For setting the network connections on the Instrument, refer to **§3.3.11**.

4.4 Functionalities

4.4.1 NETWORK VIEW

SCREEN	DESCRIPTION
	<p>NETWORK VIEW</p> <p>This provides information on the NextGen devices that are connected to the network.</p> <p>If the list is empty, click SCAN/REFRESH to scan the devices connected to the network. Please refer to the TMA Operations Manual section 2.3.3 Network Discovery (NET SCAN) for more details.</p> <p>Once the list is filled, look for the MTS-3050 model and check if the device is online or offline.</p> <p>If offline, the device needs to be manually turned on. If online, click the device to enable the TEST and MANUAL TEST tabs.</p> <p>Navigate to the METER DATABASE tab, select a meter information, and click USE IN TEST button to proceed with the test.</p> <p>For more details, please refer to the TMA Operations Manual section 2.3.4 View Scan Details and 2.3.5 Network View Functionality.</p>

4.4.2 METER TEST

SCREEN	DESCRIPTION
	<p>METER TEST This is where the test is conducted. Results will also be displayed here as the test is being executed. For more details on the configurations for the test, please refer to the TMA Operations Manual section 2.3.6 TEST.</p>


4.4.3 METER DATABASE

SCREEN	DESCRIPTION
	<p>METER DATABASE This enables the management of meter information saved in the application database. For more details on meter database configuration, please refer to the TMA Operations Manual section 2.3.7 METER DATABASE TAB.</p>

4.4.5 TEST SEQUENCE

SCREEN	DESCRIPTION
	<p>TEST SEQUENCE This is used to configure test sequences. It allows creating, copying, and deleting test sequences, as well as setting up complex test scenarios that can be run on the TEST panel. For more details on test sequence configuration, please refer to the TMA Operations Manual section 2.3.9 TEST SEQUENCE TAB.</p>

4.4.6 MANUAL SETUP

SCREEN	DESCRIPTION
	<p>MANUAL SETUP</p> <p>This allows the user to adjust all system parameters on the fly and run a single test at a time. It does not use predefined sequences. For more details on conducting a manual test, please refer to the TMA Operations Manual section 2.3.10 MANUAL SETUP TAB.</p>

5.0 MAINTENANCE

5.1 Introduction 28

5.2 Replacing the Fuse 28

5.3 Cleaning the Air Filters 29

5.4 Cleaning the Instrument External Surface 30

5.1 Introduction

This chapter explains how to perform the routine user maintenance required to your Instrument in optimal operating condition.

The topics covered in this chapter include:

- Replacing the Fuse
- Cleaning the Air Filter
- Cleaning the Instrument External Surface

5.2 Replacing the Fuse

The power fuse IS accessible from the Instrument's rear panel. See Figure 5.2.




Figure 5.2 MTS-3050 Fuse Location

WARNING

To avoid electrical shock or personal injury, ensure that the Instrument is switched off and disconnected by removing the line power cord from the power input socket before attempting to access the power fuse.

To access & replace the fuse, proceed as follows:

1. Disconnect line power.

2. Using a standard 5mm wide screwdriver, insert it to the slit and pull upwards for both ends until the cap and fuse are disengaged.
3. Pull the fuse holder and replace the defective fuse. Use below the recommended fuse ratings and manufacturer in Table 5.2.
4. Return the fuse holder by pushing down the cap until it completely closes.

Table 5.2. Recommended Fuse Replacement


Description	Voltage	Amperage
AC DC Fuse Cartridge, Glass, Time Delay, 5mm x 20mm	250V	5.0A

5.3 Cleaning the Air Filters

The fan air filters are accessible from the left-side front of MTS-3050. See Figure 5.3a.

CAUTION 

Damage caused by overheating may occur if the area around the fan is restricted, the intake air is too warm, or the air filter becomes clogged. The air filter must be removed and cleaned at least every 30 days or more frequently if the Instrument is operated in a dusty environment.



Inflow Filter 1 protects the heating elements of Power Board circuitry compartment from the dust that comes in together with the air inflow.

Figure 5.3a MTS-3050 Fan Filter Location

To access and clean the air filters, proceed as follows:

1. Disconnect line power.
2. Remove the filter retainer by holding its two upper corners or two lower corners and pulling it outward until it disengages from the fan guard.
3. Remove the air filter that is in between the Filter Retainer and Fan Guard. See figure 5.3b.
4. Clean the filter by washing it in soapy water. Rinse and dry it thoroughly before reinstalling.
5. Place the filter at the back of the retainer.
6. Reinstall the retainer in the fan guard. The retainer is snapped on the four sides for the fan guard.




Figure 5.3b: MTS-3050 Fan Filter Assembly

5.4 Cleaning the Instrument External Surface

Clean the exterior of the instrument using a soft cloth slightly dampened with either water or a non-abrasive mild cleaning solution that is not harmful to plastics.

CAUTION 

Do not use hydrocarbons or chlorinated solvents for cleaning. They can damage the plastic materials used in the Instrument.

6.0 CONFIGURATIONS


6.1 Single Test 32

6.2 Sequence Test..... 32

6.3 Disconnect Test..... 33

6.4 PLC Test 34



6.1 Single Test

SCREEN	STEPS
	<ol style="list-style-type: none"> 1. From the MAIN MENU, press F1 to access MANUAL TEST. 2. Configure the Drive Setup. Once everything is set, press F4 to access METER INFO. SOCKET. 3. Enter the meter's details and press F4 to proceed with the SINGLE TEST SETUP. 4. Configure as desired. Only one test type can be selected per test. 5. Press F4 to begin the test.


6.2 Sequence Test

SCREEN	STEPS																								
 <table border="1" data-bbox="203 1339 782 1558"> <thead> <tr> <th>ENA</th> <th>TAG</th> <th>MODE</th> <th>WAVEFORM SETUP</th> <th>Time/Puls/Revs</th> <th># of Tests</th> </tr> </thead> <tbody> <tr> <td><input checked="" type="checkbox"/></td> <td>#1</td> <td>FL</td> <td>ACCURACY 4W,WYE FL 120V, @TA PF=1 SINUSOIDAL</td> <td>5 Pulses</td> <td>1</td> </tr> <tr> <td><input checked="" type="checkbox"/></td> <td>#2</td> <td>LL</td> <td>ACCURACY 4W,WYE LL 120V, @0.1TA PF=1 SINUSOIDAL</td> <td>1 Pulses</td> <td>1</td> </tr> <tr> <td><input checked="" type="checkbox"/></td> <td>#3</td> <td>FLPF</td> <td>ACCURACY 4W,WYE FLPF 120V, @TA PF=0.5 SINUSOIDAL</td> <td>3 Pulses</td> <td>1</td> </tr> </tbody> </table>	ENA	TAG	MODE	WAVEFORM SETUP	Time/Puls/Revs	# of Tests	<input checked="" type="checkbox"/>	#1	FL	ACCURACY 4W,WYE FL 120V, @TA PF=1 SINUSOIDAL	5 Pulses	1	<input checked="" type="checkbox"/>	#2	LL	ACCURACY 4W,WYE LL 120V, @0.1TA PF=1 SINUSOIDAL	1 Pulses	1	<input checked="" type="checkbox"/>	#3	FLPF	ACCURACY 4W,WYE FLPF 120V, @TA PF=0.5 SINUSOIDAL	3 Pulses	1	<ol style="list-style-type: none"> 1. From the MAIN MENU, press F2 to access TEST SELECTION. 2. Press F1 to open METER INFO SOCKET 1 screen and enter the meter's details. 3. Press F4 to open SEQUENCE SETUP screen and choose the desired SEQUENCE TEST. 4. Press F4 to begin with the test and view the live feed for the results.
ENA	TAG	MODE	WAVEFORM SETUP	Time/Puls/Revs	# of Tests																				
<input checked="" type="checkbox"/>	#1	FL	ACCURACY 4W,WYE FL 120V, @TA PF=1 SINUSOIDAL	5 Pulses	1																				
<input checked="" type="checkbox"/>	#2	LL	ACCURACY 4W,WYE LL 120V, @0.1TA PF=1 SINUSOIDAL	1 Pulses	1																				
<input checked="" type="checkbox"/>	#3	FLPF	ACCURACY 4W,WYE FLPF 120V, @TA PF=0.5 SINUSOIDAL	3 Pulses	1																				

6.3 Disconnect Test

SCREEN	STEPS
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Figure 6.3.1-Disconnect test in enabled state.</p> </div> <div style="text-align: center;">  <p>Figure 6.3.2-Successful disconnect test.</p> </div> </div>	<ol style="list-style-type: none"> 1. From the MAIN MENU, press F2 to access TEST SELECTION. 2. Press F4 to enter DISCONNECT TEST. The green DISCONNECT TEST indicator will turn on. 3. Press F1 to enable service voltage to socket. 4. Optional: To set load current, press CURRENT to highlight load current data box and enter desired value. 5. Optional: Press F2 to enable load current. Note: BACKVOLTAGE will enable automatically. 6. Once voltage is applied, and the meter service disconnect is closed, the red JAW HOT indicators will turn on. Refer to Figure 6.3.1. NOTE: For Form 1S, the JAW4 HOT indicator will not turn on. 7. Open the meter service disconnect. If successful, the JAW HOT indicators, LOAD current and BACKVOLTAGE (if enabled) will all turn off. Refer to Figure 6.3.2. 8. If BACKVOLTAGE is turned on separate from LOAD, it will not turn off automatically if the meter disconnect is opened. BACKVOLTAGE can be turned on while a meter disconnect is opened. If BACKVOLTAGE is on, but the meter disconnect is open, the JAW HOT indicator lights will turn on.

6.4 PLC Test

SCREEN	STEPS
	<ol style="list-style-type: none"> 1. From the MAIN MENU, press F2 to access TEST SELECTION. 2. Press F3 to access PLCT TEST. 3. Press F1 to enable service voltage only to socket or press F2 to enable both service voltage and current to socket. The results will show once voltage and load are enabled.

7.0 FREQUENTLY ASKED QUESTIONS

7.1 Introduction	36
7.2 Test	36
7.3 Software.....	36
7.4 Hardware.....	36

7.1 Introduction

This section aims to answer frequently asked questions when operating the Instrument. Some of these answers refer to certain sections in this manual to provide more information.

7.2 Test

1. Is it possible to perform multiple types of test simultaneously?

Only one type of test can be executed at a time.

2. How many repetitions can I set for a test?

The limit for test repetitions is 99.

3. What meter forms can be tested?

The device can test most, if not all, meter forms. For a complete list of the forms, see section **1.6.2 Standard Features**.

7.3 Software

1. How can I obtain the firmware update file?

You can directly contact TESCO through phone or email. For the contact details, see Section **1.2 Contacting TESCO**.

2. When should I update the software?

Updates are managed by TESCO. For contact details, see section **1.2 Contacting TESCO**.

3. How frequent are the updates?

Updates are managed by TESCO. For contact details, see section **1.2 Contacting TESCO**.

7.4 Hardware

1. Where/Who can I ask for replacement parts?

For repair concerns, please contact TESCO. See section **1.2 Contacting TESCO**.

2. Are there any tests I can perform to check hardware performance?

For maintenance concerns, please contact TESCO. See section **1.2 Contacting TESCO**.

8.0 TROUBLESHOOTING

8.1 Troubleshooting 38

8.1 Troubleshooting

1. No Power-Check.

Make sure the power cord is plugged into the outlet. Check the power outlet, fuse, or circuit breaker.

2. Test won't be able to proceed.

Check if correct meter form is selected.

3. I inserted a meter, but when I try to start a test, the unit prompts me to insert a meter.

The meter may not be fully seated. Press the METER RELEASE button, remove the meter, and reinsert the meter into the socket. Make sure you hold the meter in place until the METER RELEASE indicator light turns on.

For more information on troubleshooting, please contact TESCO. See section **1.2 Contacting TESCO** for contact details.