

OPERATING INSTRUCTIONS – CATALOG NO. 326 LOAD BOX

Before connecting any leads to the Catalog No. 326:

- 1. Determine the voltage of service
- 2. Move Full Load/Light Load switch to "OFF" position
- 3. Set current select switch to desired test amps
- 4. Connect current and potential leads to the Catalog No. 326 Load Box and meter under test

CAUTION: NO SWITCHING OR CHANGING OF CURRENT LEADS SHOULD BE MADE UNLESS THE FULL LOAD/LIGHT LOAD SWITCH IS FIRST PLACED IN THE OFF POSITION.

Make potential and current connections to two-wire energy source and meter under test according to your company's meter test diagrams.

Set Full Load/Light Load switch to desired position.

Perform watt-hour meter test according to your company's testing procedures.