

OPERATING INSTRUCTIONS

CAT. 254 SERVICE DISCONNECT ADAPTER

TESCO's Service Disconnect Adapter (Catalog No. 254) disconnects customer load, while maintaining power to the meter, and tilting the meter to a 45° angle. The meter continues reading and communicating for AMR/AMI operations, while disabling service on the load side.



1

Locate and prepare meter socket where disconnect adapter is to be inserted.

CAUTION 
Accessing meter socket may require assistance from an authorized technician especially those enclosed in tamper-sealed meter boxes.

2

Insert disconnect adapter into meter socket.

NOTE
To ensure correct orientation, align disconnect adapter to meter socket based on the position indicator (*right*) in the adapter.



3

Insert meter to disconnect adapter at 45° angle with respect to the position indicator.