



**OPERATING INSTRUCTIONS – CATALOG NO. 900 Service Ground Test Set**

**Directions:**

1. Connect outgoing leads to voltage source, read voltage on top scale of meter.
2. If there is no indication on the meter, depress button marked 130v. Read voltage on bottom scale of meter.
3. After determining correct voltage range, test for ground resistance by depressing button marked "Ground Test". Voltage drop will indicate ground resistance.

